



INTRODUCTION

SYMMIC from CapeSym is a template-based thermal simulator that has been optimized for monolithic microwave integrated circuit (MMIC) design. This application note demonstrates the integration of Microwave Office and SYMMIC. The integration is script-based and requires minimum manual intervention as compared to non-integrated thermal solvers. The example used here is an extension of the MMIC high power amplifier (HPA) example that is part of the standard Microwave Office set of examples.

BACKGROUND

SYMMIC's template based approach allows the user to define the process technology and thermal stackup separately from the circuit layout. These templates can then be reused for different designs. Once a template is defined for your GaAs MMIC, for example, it's a simple matter to switch to an RF/microwave design focus—simply updating the layout and DC power settings in SYMMIC—to analyze the thermal performance of your designs. SYMMIC can be used beyond the MMIC for modules and subsystems, as well as for transient and steady-state analysis with flexible boundary conditions that includes radiative effects.

This application note will focus on a MMIC in steady-state to show the basic operation and utility of the integration and the ease of use of SYMMIC with Microwave Office.

It is assumed that SYMMIC has been installed on the same computer as Microwave Office and that the Microwave Office script provided by SYMMIC has been installed properly within the AWR Design Environment™.

WHAT MAKES SYMMIC DIFFERENT?

Most thermal analysis tools are optimized and designed for general problems in thermal simulation. This generalization makes them difficult to learn and use.

SYMMIC takes a totally different approach to significantly reduce complexities and barriers for a MMIC designer. The template-based notion of thermal design relieves the electrical engineer from nearly all the burden of creating robust thermal simulations. To be sure, issues like thermal boundary conditions and material properties still need to be understood, but the particulars involved can be investigated as part of the design process and not a precursor to it. SYMMIC is the first tool that brings thermal analysis to the realm of MMIC design.

What's more SYMMIC is fast. If you have a desktop workstation that uses a multi-processor, 64-bit AXIEM®, SYMMIC can take full advantage of this same hardware configuration. The simulations in this application note were run on an 8-core 16GB Windows PC running 64-bit XP. This is highly conducive to an iterated design flow where FET bias points can be chosen with regard to thermal conditions as well as electromagnetic. It is entirely possible to now design concurrently for reliability and electrical performance.



SYMMIC Thermal
Simulation from
Microwave Office
Projects

As with any analysis tool—and MMIC designers are well aware of this with EM analysis—an absolutely necessary condition for successful and productive use is to profile them against known problems or laboratory measurements. One of the difficulties in doing this with thermal analysis and MMIC design is that there is a great deal of variability in the various methods used to measure channel temperatures¹. While this may create controversy in the minds of some engineers as to the absolute temperature values indicated by a thermal analysis, tools like SYMMIC are still powerful guides to trends and relative values.

STEP 1 - INITIAL ELECTRICAL DESIGN

Three easy steps using SYMMIC:

1. Develop your MMIC design as you normally would. When the design has progressed far enough that you have a layout containing thermal sources then you will be able to run the SYMMIC script.
2. Prior to running the script, set up an annotation on your MMIC-level schematic using TOT_PWRA. This annotation will provide the proper information for SYMMIC to use as the heat source(s) for the thermal analysis.
3. In this application, we simply open the HPA_MMIC.emp file. From this basic design, an initial low noise amplifier (LNA) design is added simply by taking two of the FETs already in the design, copying them, and rebiasing them so their drain current is about 10% of that for field effect transistors (FET) in the PA stage(s).





Figure 1. HPA + LNA design.

Figure 2. Simple LNA design starting point added for early thermal analysis.



STEP 2 - PREPARE AND RUN MICROWAVE OFFICE SYMMIC SCRIPT

In this section, the SYMMIC data is created in Microwave Office and prepared for exporting to SYMMIC.

1. First, run the script from the Script pull-down menu. Depending on how the script was installed in the AWR Design Environment, this script will appear in different places: global scripts or project scripts. (See the AWR Design Environment User Manual if you cannot find the script or the proper procedure for its installation.) The script begins by prompting you for the layout that will be used for the physical data and the schematic that will be used for the electrical information (figure 3).
 2. The schematic containing the entire MMIC layout should be selected from the first column (here, HPA_MMIC). The schematic containing the placed MMIC which has the TOT_PWRA annotation should be selected from the second column (here, -NL_WholeAmp).
 3. Click Begin Layout. Two windows open. SYMMICLayout is a datafile window, which will be populated xml information describing the FETs and their location. SYMMICPwr is a table-formatted graph which will display the annotated power information from the TOT_PWRA annotations for the devices you select. Note: If you do not select the Create Power Table From checkbox in the dialog (figure 3), then the graph will not be created. The graph does not need to be created as the information can be read directly from the related schematic and entered manually in SYMMIC.
- In the next few steps, the layout hierarchy is traversed to find the devices which will be used as sources and analysis points within the thermal simulation.

4. Click the Browse button and select a template to use for the chosen devices. The templates are *.xml files exported from SYMMIC and are technology-based. Since the HPA_MMIC has been previously analyzed by SYMMIC, templates are already available for the FETs. These device templates contain all of the material and layout information regarding the device. The electrical information is stored separately. This allows for fast transfer of data from Microwave Office to SYMMIC as it reduces the datafile size where FETs of common size are re-used in the design. This also allows SYMMIC to separate material and layout information from electrical power dissipation information which speeds up iteration time as bias schemes vs. temperature are explored.




Figure 3. SYMMIC thermal analysis script - dialog 1: Selection of MMIC layout and MMIC electrical information.




Figure 4. SYMMIC thermal analysis script - dialog 2: From the top-level hierarchy the layout is traversed to find the source/analysis devices.

If this were a new MMIC design using a different FET periphery, the design would need to be imported into SYMMIC and the xml template updated from within SYMMIC. Consult the SYMMIC documentation for more information.

Once the xml template is available for a given device layout, it is re-useable for all devices with that layout even if they have different power dissipations.

5. From the Analyze Selected Devices box, select the device you wish to include in the thermal analysis. A device template in SYMMIC often models half of a symmetrical device. If you wish to analyze the entire device in the simulation using mirror symmetry, click the checkbox Mirror Template in X. The Angle Of Device Relative To Template dropdown item can be used to indicate the difference in orientation of the device in the MWO library in your layout as compared to how it was stored in relative to that of the template in SYMMIC.
6. For the device selected in step 5 above, find the hierarchical element corresponding to the layout cell for that device. In the case of the OutputFET selected in figure 4, we must go down 1 level of hierarchy. To do this, click the Enter Hierarchy Subcircuit button and select all of the elements associated comprising the artwork described by the template. In figure 5, the eight elements selected all use this single template.
7. Click Add To Layout to add these devices to the layout to be analyzed. The SYMMIClayout datafile window is updated with the identifying information and locations for these devices.
8. Repeat steps 5 through 7 for all the devices you wish to include in the analysis.
9. Once all the devices have been selected for inclusion in the analysis, click the Complete button to finalize the SYMMIClayout and exit the script.
10. From the Data Files node of the project palette, find the SYMMIClayout file, right mouse-click and select Export Data File. You must include the .xml extension to the file name before exporting the design. You are free to name the file whatever you want, but it must include the .xml extension.
11. Simulate your circuit to get the TOT_PWRA annotation values or to calculate the values in the power table, if generated.




Figure 5. SYMMIC thermal analysis script - dialog 3: Select devices corresponding to layout cells which are to be analyzed using the template outputFET.xml. Clicking "Add to Layout" will force these to appear in the SYMMIClayout data file.




Figure 6. SYMMIClayout data file created by the SYMMIC script in Microwave Office.




Figure 7. Exporting the xml file from the Data Files node of the Project palette.

STEP 3 - IMPORTING LAYOUT INTO AND ANALYZING WITH SYMMIC

SYMMIC is a stand-alone application run separately from AWR software. SYMMIC can be run anytime after the SYMMIClayout datafile is exported as an xml file from Microwave Office. Additionally, for each device in the desired thermal analysis, it will be necessary to have the total dissipated power, from the TOT_PWRA annotation, as additional input data for the SYMMIC simulation.

For a detailed guide to the use of SYMMIC, see the SYMMIC user documentation. As an example, step-by-step instructions are given here using the HPA with the added LNA.

1. Start the SYMMIC application.
2. Import the layout by going to the File pull-down menu and opening the xml file exported from Microwave Office.
3. Input the device dissipated power for each device by going to the Device pull-down menu, and using the Device selection command to select a device. Then, open up the heat generation dialog (from the same pull-down menu), and update the power based on the TOT_PWRA annotation from Microwave Office (figure 8) by selecting the first row Total ON Power and right-mouse clicking Edit. Change the selected device and repeat/validate that all your devices have the proper power.

Additional parameters for the device can be edited from this dialog. See the SYMMIC documentation for more details.

4. Run the thermal analysis from the Solve pull-down menu.
5. Results can be viewed from the results pull-down menu.




Figure 8. SYMMIC with imported xml file and dialog for updating/verifying dissipated power for each FET.

RESULTS FOR HPA+LNA

Two different simulations were run with HPA+LNA MMIC. In the first simulation (figure 9), the HPA is off and the LNA is running at its nominal value of 50 mW. The channel temperature for the LNA FETs is approximately 8 deg above baseplate.

In the second simulation, the HPA and the LNA are both operational. The HPA is running at approximately 450 mW dissipated power per FET in the output stage and in the driver stage—clearly this is an exceptionally “hot” test condition. In this configuration (figure 10), the output stage FETs vary over about 20 deg C, with the hottest FET running almost 90 deg C above baseplate. The LNA FETs though are now about 13 deg C above the baseplate—perhaps a bit warmer than when they are the only thermal source, but not as hot as one would expect with the HPA in an extreme condition.

CONCLUSION

Thermal simulation is now a reality for the MMIC designer not as an esoteric piece of mechanical engineering software, but as an integrated part of an RF/microwave design flow. SYMMIC's template-based approach and sheer simulation speed combined with its scripted integration to Microwave Office means that more accurate device simulation is possible for electrical circuit design. Reliability can be concurrently considered with electrical performance in simulations that take no longer than a detailed, 3D planar EM simulation.




Figure 9. SYMMIC simulation for HPA + LNA MMIC with HPA off and LNA at nominal.




Figure 10. HPA and LNA running simultaneously.



AWR, 1960 East Grand Avenue, Suite 430, El Segundo, CA 90245, USA
Tel: +1 (310) 726-3000 Fax: +1 (310) 726-3005 www.awrcorp.com

Copyright © 2011 AWR Corporation. All rights reserved. AWR and the AWR logo, and AXIEM are registered trademarks and AWR Design Environment and Microwave Office are trademarks of AWR Corporation. All other trademarks are trademarks of their respective owners.